

Supramolecular Stereochemistry in Liquid Crystals

David M. Walba and Noel A. Clark

***Department of Chemistry and Biochemistry, Department of Physics,
and the Liquid Crystal Materials Research Center
University of Colorado at Boulder***

- ◆ ***High throughput measurement of ee
using FLC EO***
- ◆ ***Banana phases and the first fluid
conglomerates***




Stereochemical Aspects of Novel Materials
UCSB, August 2005




A Liquid Crystal Conglomerate?

- ◆ **No chiral LC phase from achiral or racemic molecules was known.**
- ◆ **Observation of a chiral LC phase is often used as proof of molecular enantiomeric excess.**



Banana Phases






- ◆ 1929 Vorländer describes the first banana LCs
- ◆ 1992 Cladis, Brand and Pleiner suggest possibility of polar Sm “chevron” bilayer with C_{2v} symmetry and helical chirality
- ◆ 1994 Matsunaga reports certain achiral bent mesogens give smectic C phases.
- ◆ 1996 Takezoe and Watanabe et al report these “banana-shaped” molecules produce ferroelectric phases with C_{2v} layer structure and helical chirality, starting a wave of **banana mania** in the FLC community
- ◆ 1997 The Boulder Group proposes **a chiral layer structure for the B2 phases**


NonyloxyBOW (NOBOW): B4 — 155 → B2 — 173 → I

B2 Layer Structure

Spontaneous Nonpolar AND Reflection Symmetry Breaking



The arrows are all pointing in the same direction, and the director is tilted, giving a C_2 layer structure. This symmetry is both polar and chiral.




Nonsuperposable Mirror Images




Ferro and Antiferroelectric Chiral Smectics


C_2




Synclinic Ferroelectric




D_2







Anticlinic Antiferroelectric






The B2 Conglomerate is Antiferroelectric




(-) NOBOW Antiferro EO Switching





- Stereogenic Elements**
- ◆ Layer Chirality
 - ◆ Layer Pair Clinicity
 - ◆ Layer Pair Polarity




**Antiferro
Phases
Common**


**Ferroelectric
Phases
Rare**

A Ferroelectric Banana?

- ◆ Most calamitic chiral smectics are **ferroelectric** (antiferroelectrics are very rare)
- ◆ Most bananas are **antiferroelectric**
- ◆ Glaser theory: Syn-clinic is favored entropically due to **out-of-layer fluctuations**
- ◆ Suppression of OLFs by the molecular structure allows anticlinic layer interfaces to appear in the phase sequence.
- ◆ By far the best way to achieve this:
The famous MHOC tail
- ◆ The SmC_A anticlinic phase occurs in both unichiral and racemic MHPOBC




Calamitic Smectics



Ferroelectric SmC^*
Common

Antiferro SmC_A^*
Rare













Bananas




Antiferro $SmC_S P_A$
Common

Ferroelectric $SmC_S P_F$
Rare

MHOBOW: A $SmC_S P_F$ by Control of Clinicity



Make it a "bilayer"





Tilt plane of SmC_A

Bow plane of $SmC_S P_F$




The Amazing KYOBOW from Tokyo Tech!




KYOBOW is Unichiral, but forms a SmC_AP_F Ferroelectric Racemate!


Tilt Plane



Polar Plane



- ◆ **Minority domains are a conglomerate showing the chiral EO of a SmC_SP_F phase.**
- ◆ **Majority domains show no EO switching, but a strong ferroelectric polarization reversal current.**
- ◆ **Focal conic domains are immiscible with the NOBOW SmC_SP_A phase in the absence of a field, but become miscible upon application of a field, where both materials are in the SmC_AP_F structure.**




**H. Takezoe
J. Watanabe
M. Nakata
D.R. Link
Et al**

The SmCP Story was an FLC Paradigm Shift

Meyer paradigm: 1974 - 1997

The SmC has C_{2h} symmetry;
molecular enantiomeric enrichment
is required for polar symmetry



Tilt Plane \equiv Normal to C_2
Polar Plane \equiv Contains C_2 and z




FLC Paradigm Shifting Runs Amuck

◆ Claims of parity violation

- Goodby 2005 Chem. Commun. (unichiral FLC from a racemate)
- Goodby 2001 J. Mater. Chem. (unichiral FLC from achiral mesogen)

◆ Claims of spontaneous reflection symmetry breaking

- Kishikawa 2005 JACS (achiral calamitic phenylbenzoate makes a chiral SmC phase!)
- Niori 2004 MCLC (chiral nematic from an achiral bent-core mesogen)
- Takezoe and Watanabe 2002 JACS (doping an achiral bent-core mesogen into a chiral nematic tightens the pitch)
- Takezoe 1999 Angew. Chem. IE (spontaneous de-racemization of enantiomers in a SmC)
- Komitov 1998 Liq. Cryst. (chiral nematic from achiral mesogen)




**The conformational
chirality hypothesis
in LCs**

Mauguin's Twisted Nematic




Louis Pasteur



**Chiral Sodium Ammonium
Racemate Crystals, 1848**





Charles Mauguin



**Mauguin's Twisted Nematic
Liquid Crystal, 1911**


- ◆ Spontaneous reflection symmetry breaking in LC systems **driven by surface constraints** is very common.
- ◆ But, **no chiral LC phase** from achiral or racemic molecules had been seen.
- ◆ Observation of a chiral LC phase is often used as proof of molecular enantiomeric excess.

Unichiral SSFLC Electro-optics




Enantiomeric EO Response

$P > 0$ (right-handed)






$$P = f(ee)$$

$P < 0$ (left-handed)



Weird Observation from the '90s




$P \sim -500 \text{ nC/cm}^2$

We were shocked to discover that samples of racemic 2-octanol led to W314 samples showing unichiral electro-optics in SSFLC cells!

Response suggests $\sim 0.3\%$ ee?

- ◆ **Parity violation? We think NOT.**
- ◆ **SSFLC switching is one of the most sensitive detectors of chirality...**



...and the Volume of Material in the Pixels is Small



Pixel volume as small as $25 \mu\text{m}^3 = 25 \text{ fL} \sim 25 \text{ pg}$

...Suggests Possible New Applications

- ◆ **Search for enantio-enrichment on Titan**
 - Requires fast, high sensitivity method for sensing ee remotely
- ◆ **Chirality detectors for combinatorial asymmetric catalyst development**
 - Key to development of asymmetric catalysts using combinatorial methods
 - Requires high throughput and good discrimination in the 50% - 100% ee range
 - Conventional method: 15,000 analyses in several months by HPLC
 - Current published state of the art: 15,000 analyses in 48 hrs using reaction microarrays



The Harvard chirality detector


M. Shair et al. *J. Am. Chem. Soc.*, 123, 361 (2001)

First Approach to FLC Chirality Detector


- ◆ *Pick an achiral or racemic SmC host (e.g. racemic W314)*
- ◆ *Dope with sample of unknown ee*
- ◆ *Determine ee using SSFLC electro-optics*
- ◆ *Adapt the method for use in a large array of physically separated pixels*

$$\tau = \frac{\eta}{P * E} \quad P = f(ee)$$

Behavior of the Authentically Racemic Host is Surprising




- ◆ The EO response of authentic rac-W314 is complex
- ◆ After a few hours under drive, chiral domains can be observed
- ◆ After a month under drive, the entire sample segregates into two heterochiral domains



Heterochiral domains formed in rac-W314





Determination of ee in domains from careful risetime measurements





$$\frac{1}{\tau} = \left(\frac{P}{\eta} \right) E$$

PE Can Drive Partial Deracemization (~4% ee)

“extras” in a smectic C



In the presence of a field
 $G = -P_s (ee) E + 1/2 kT ee^2$



$$ee_{ss} = pE / k_B T$$


$$p = P_s / \text{molecule}$$

For Chirality Detector SmC is Problematical

G2 Approach: Electroclinic Chirality Detection

- ◆ ***E-field induced deracemization is cool, but chirally doped racemic W314 is not useful for measurement of ee in our hands***
- ◆ ***Preliminary work using achiral SmC hosts uncovered several other interesting complexities (i.e. it doesn't work)***
- ◆ ***Can the **electroclinic effect** in doped achiral SmA hosts produce a useful chiral signal?***

The Electroclinic Effect in the SmA*




Effectively an E-field induced SmC with collective polarization*

Only happens with chiral liquid crystal

- ◆ *Bob Meyer also predicted the **electroclinic effect** in SmA* materials*
- ◆ *At $E = 0$ there is no net tilt in a SmA**
- ◆ *Due to free energy gain from combining an **applied E field** with the **collective polarization** in tilted chiral smectics, a tilt is induced in the SmA* with applied E*
- ◆ *$\theta \propto E$ for small E*

Doping a SmA Host (EK992)

Host: EK992




80% $R_1 = C_8H_{17}$; $R_2 = OC_6H_{13}$

5% $R_1 = C_8H_{17}$; $R_2 = OC_{12}H_{25}$

15% $R_1 = C_{10}H_{21}$; $R_2 = OC_6H_{13}$

SmC - 43 - SmA - 59 - N - 65 - I

Dopant: Naproxen




Various ee, enriched in (S)

◆ The chiral signal




- Electroclinic electro-optic modulation depth ΔI between crossed polarizers ($I_{E\ on} - I_{E\ off}$ with the cell oriented for maximum ΔI)

◆ Conditions of the measurements



- Sample: Host doped with 1% by weight naproxen samples of various ee
- EO cell: 3.7 μm gap ITO/glass with parallel-rubbed low pretilt PI alignment layers
- EO measurement: $V_{App} = \pm 10\text{V}$ square-wave drive @ 1KHz, HeNe laser probe (spot size 20 x 20 μm), I measured with a photodetector (V)



A deVries Cell



Data Obtained with EK992 Host



The good news: The chiral signal provides a good measure of naproxen ee.



The bad news: T_{AC} is different for each sample. Since the electroclinic effect is strongly dependent upon reduced temperature, the data had to be taken at a constant reduced temperature, which was a different absolute temperature for each sample.

This method cannot be applied to a high throughput measurement device.



deVries Smectics to the Rescue

- ◆ For “normal” SmA* materials the electroclinic tilt is small, and highly dependent on $T - T_{AC}$
- ◆ deVries SmA* materials (very rare) in general seem to show a much larger tilt, and much less temperature dependence than normal SmA* materials


Normal



deVries



Host W435 (a deVries material)



W435 (racemic W415)



SmC - 24 - SmA - 33 - I

◆ Conditions used for the measurements

- Host doped with 1% by weight of several naproxen samples of various ee
- Sample filled into an ITO/glass LC cell with one rubbed and one unrubbed nylon (elvamide) alignment layers
- ΔI measured as before


This method can be amazingly sensitive (W415 of ~ 0.01 % ee detectable)

Method works at a single temperature



- ◆ Chiral signal from 1% **Naproxen** in achiral deVries SmA host
- ◆ Measurement good to about $\pm 5\%$ ee
- ◆ Signal from about 10 pgm of Naproxen
- ◆ Adaptable to **really** high throughput measurement of ee


Results with Pseudoephedrine



- ◆ 1% by weight pseudoephedrine in W435 gives a smaller signal than naproxen
- ◆ Consistent data was difficult to obtain, due to the volatility AND insolubility of the pseudoephedrin in W435

Conclusions



- ◆ *The achiral deVries host gives a huge signal compared to the non-deVries host*
- ◆ *The signal is linear with ee of the dopant*
- ◆ *Though the $T-T_{AC}$ was different for the mixtures, in the deVries host the signal was relatively temperature independent, allowing for measurement of the ee of multiple samples at one absolute temperature*
- ◆ *It is necessary to “scan around” the cell to find a well-aligned region*
- ◆ *This method could in principle be applied to a large number of samples in parallel (in physically separated “pixels”) if uniform alignment could be obtained*
- ◆ *The actual amount of naproxen in the probe beam is ~ 10 pgm (10^{-11} gm)*
- ◆ *This method could be applied to ~ 0.25 pg ($5 \times 5 \mu\text{m}$ pixels)*
- ◆ *Optimization of the host is possible*



What Now?

- ◆ **Measure ee of the product of some asymmetric reactions**
 - *Homogeneous mixture?*
 - *Interference from catalyst?*
- ◆ **Develop a parallel method - measurement “pixels” in an array**
 - *ee microdisplay has physically separated pixels, uniform electronics (should be much less expensive than video microdisplays)*
 - *Very relaxed lifetime specification suggests high yield manufacturability...*
 - *Is it possible to get the required “clean molecular alignment”?*
- ◆ **Key issue - low conversion is indistinguishable from low enantioselectivity**

Banana Mania



Design, Synthesis, PLM

Dave Walba, Eva Körblova

PLM, X-ray, DRLM, FFTEM, Simulations

Noel Clark

Dave Coleman

Michi Nakata

Joe MacLennan

A Chattham

Renfan Shao

Matt Glaser

Darren Link

John Fernsler

**\$\$ The Liquid Crystal Materials Research Center
(NSF MRSEC)**

Chirality Detector

Noel A. Clark


Eva Körblova

Lior Eshdat

Renfan Shao

Jan Lagerwall

Alex Kane



Ferroelectric Liquid Crystal
Materials Research Center

an NSF MRSEC

21st International Liquid Crystal Conference

Keystone, Colorado
July 2 - 7, 2006



Enjoy Keystone




Explore Colorado



See the West



ILCC 2006 www.ilcc2006.com



Organized by the
Liquid Crystal Materials Research Center
University of Colorado, Boulder



Join the largest international conference featuring exciting new liquid crystal science & technology

supermolecular ordering
LC bioscience & technology
lyotropics, colloids, & composites
self-assembly and new phases

frontiers of chirality
optics & photonics
LC nanoscience
exotic soft materials